

1. Electric connection

Radio drive without switch



Radio drive with switch



1 = PE, yellow-green
2 = L1, brown
3 = DOWN, black
4 = UP, grey
5 = N, blue

Connection of a permanently installed switch is optional. Connection via N, L1 and PE is sufficient for radio control only.